




IMS3X78DR - EXPLODED VIEW



SPARE PARTS

	Code	Pieces
1	11201007000039	Room temperature sensor
3	15822000008240	Condenser assembly
4	11201007000136	Pipe temperature sensor
5	12222300000551	Valve plate
6	12222000011945	Chassis assembly
7	12222000013065	Right clapboard assembly
9	12122300000130	Shield
11	12222000004822	Front panel
12	12122000020242	Air outlet grille
13	12100105000181	Axial flow fan
14	11002015008365	Brushless DC Motor
15	12222000004884	Supporter subassembly of fan motor
16	15422000014714	Gas valve assembly
16.1	15500204000021	Gas valve
17	12222000009205	Top cover assembly
18	12222000004794	Left side plate assembly of cabinet
19	12222000004784	Partition board assembly
20	17222300002272	Electronic control box subassembly
20.1	12122300000044	Cover of electronic control box
20.2	17122300002914	Main control board subassembly
20.3	17122000044656	Inverter control board subassembly
20.3.1	11203803000856	Radiator
20.4	12122300000041	Support of electronic control box
21	17222300000508	Terminal board subassembly
21.1	12222300000226	Installation plate of electric parts
21.2	17400401000135	Terminal
22	15422300000446	Liquid valve assembly
22.1	15500208000028	Liquid valve
22.2	15500213000046	Electronic expansion valve subassembly
23	15422000015813	4-way valve assembly
23.2	15500216000003	4-way valve
23.3	15500506000007	Muffler
24	11103020004360	DC Inverter Rotary Compressor
26	11201007003124	Discharge Temperature Sensor
28	17400306000058	Reactor
29	15500406000010	Copper nut
29	15500406000016	Copper nut
32	11201007000044	Pipe temperature sensor
40	17402001000603	Crankcase electric heating strip
41	17402002000466	Electric heating tube
43	12100509000059	Drain pipe
99	17401203000802	Compressor wire subassembly