




IMS5X120DR - EXPLODED VIEW



SPARE PARTS

	Code	Pieces
2	15822000007097	Condenser Assembly
3	11201007000142	Pipe Temperature Sensor
3	11201007000006	Pipe Temperature Sensor
4	12222300000510	Rear right clapboard assembly
6	12122300000090	Shield
7	12222500000633	Front right clapboard assembly
7.1	12100702000038	handle
8	12222000005272	Valve plate
9	12222000006984	Chassis assembly
10	12222000004983	Front panel
11	12122200004160	Air outlet grille
12	12100105000084	Axial flow fan
13	11002015000247	Brushless DC Motor
14	12222500000547	Supporter subassembly of fan motor
15	12222500000539	Leftside plate assembly
16	12222000001158	Partition board assembly
17	11201007000039	Room Temperature Sensor
18	12222500000587	Top cover assembly
19	17222000018428	Electronic control box subassembly
19.1	12122200002719	Electronic installing box subassembly
19.2	17122000030688	Outdoor main control board subassembly
19.4	12122200002715	Electronic installing box subassembly
19.7	17122000025435	Inverter control board subassembly
20	17222300000690	Terminal board subassembly
20.1	17400401000084	Terminal
20.2	12222300000033	Terminal board
20.3	12222300000032	Terminal board
21	15422300000350	4-way valve assembly
21.1	15500216000361	4-way valve
21.3	17400516000020	Pressure switch
21.4	15500506000007	Muffler
22	15422000010632	Liquid valve Assembly
22.1	15500208000028	Liquid valve
22.2	15500213000179	Electronic expansion valve
24	15500406000012	Copper nut
24	15500406000010	Copper nut
24	15500406000016	Copper nut
26	11103020000719	DC Inverter Rotary Compressor
29	11201007000157	Discharge Temperature Sensor
33	15422300000384	Gas valve assembly
33.1	15500204000021	Gas valve
33.1	15500204000058	Gas valve
34	15122300001024	Suction pipe assembly
34.1	17400516000024	Pressure switch
39	15500508000315	Accumulator cylinder